

Hand Carved Candle Handling & Use Instructions

This hand carved candle(s) will provide years of enjoyment and will always maintain its "new" look if it is handled and used correctly. Please follow these simple suggestions and instructions.

1. Always avoid the carved portions of the candle when lifting or moving the candle.
2. When removing the candle from the box, touch and lift by the top.
3. Once removed from the box, lift or move by grabbing the top, or the very bottom, or both in order to avoid accidental breakage.
4. The carved portion of each candle can be by design, delicate and in some instances, fragile.
5. Avoid setting the candle in direct sunlight or on warm surfaces. In general, heat and wax items are not a good combination.

WARRANTY: Each hand carved candle is warranted against defects in workmanship or materials for a period of one year from purchase date. Mishandling the candle or misuse of the wick assembly is not covered under this warranty. Further, we are not liable for injury, damage or fire occurring from burning scented oil or the use of improper "lamp oil". **CAUTION:** All lamp oil containers containing lamp oil, for your candle's consumption **MUST SAY ON THE LABEL: FOR USE IN OIL LAMPS AND OIL BURNING CANDLES!** Otherwise the oil will not burn pure! This product is not intended for the use of minors. **PLEASE** follow the "WICK" use instructions for proper care and lighting. For warranty issues please email the seller with concerns or a possible claim.

IMPORTANT CANDLE SAFETY AND START-UP INSTRUCTIONS:

1. **MOST IMPORTANT!** Adjust the wick in the slender glass tube so that the wick protrudes out of the top approximately the thickness of a dime. This will produce approximately a one inch flame. **DO NOT** burn a flame higher than one inch. A taller flame will waste the wick and could damage the surrounding wick holder and candle. To adjust the wick, pull or push up while twisting from the bottom while it is removed.
2. When removing, hold the wick holder **ONLY** as shown and not by the slender glass tube located at the very top of the wick.
3. Fill the candle with smokeless candle oil directly into the top of the candle after having removed the wick assembly unit. Fill to approximately one half inch from the top of the candle.
4. Place the wick assembly in the candle as shown in the picture. Make sure the slender glass tube is in place at the very tip of the wick. Do not light if it is missing. Contact seller for a replacement if necessary.
5. The **FIRST** time you light the wick or whenever it is dry and needs refilled, **WAIT FIVE MINUTES** for the wick to soak up the oil all the way to the top. Then light the wick.
6. **DO NOT** leave **CHILDREN** or **PETS** alone with a **LIT CANDLE!**
7. **DO NOT** light or place a lit candle near any flammable object such as: draperies, clothing, or paper (these are just a few). Remember that a draft or wind can un-expectedly move flammable materials closer to the flame.

Top of Candle / Wick Assembly

